

Maintenance

Double-Roller Crusher need to be done the maintenance work after 500 hours working as follow. .

1. Check if the V-belt is tightened well.(regulate the position of motor, the displacement of belt should not exceed 10mm when pressing in the center position of belt with your hands)
2. Check the temp. of ball bearing (for the slide block), it should not exceed 70°C after 30minutes of continuous working .
3. Check if the chain is tightened well.
4. Fixing all bolts and connectors if there is loosen.
5. Check if the machine is grounded well.
6. Lubricating all bearings and chain and gear.